



POS	ART-NO	DESCRIPTION	TOTAL	POS	ART-NO	DESCRIPTION	TOTAL
	721-260	Handpiece ICON FX PIN (without ferrule)		25	721-126	Ball bearing back joint	2x
	721-280	Handpiece ICON FX WORM (without ferrule)		26	721-127	Cog Z14	2x
1	721-261	Barrel ICON FX	1x	27	721-160-21	Drive shaft ICON PIN incl. Pos. 28	1x
2	721-102	Centre post	1x	28	721-129	Tapered pin Ø3 x 12mm	1x
3	721-103	Locknut	1x	29	721-148	Drive shaft ICON WORM	1x
4	721-104	Comb screw	2x	30	721-131	Chicken feet retaining spring	1x
5	721-105	Crankshaft	1x	31	721-132	Pan-head screw M4 x 5	1x
6	721-106	Ball	1x	32	721-133	Centre post cup	1x
7	721-107	Safety screw	1x	33	721-134	Fork body	1x
8	721-108	Oil hole cap	1x	34	721-135	Tension pin retaining spring	1x
9	721-110	Tension nut bushing screw	1x	35	721-136	Tension pin cup	1x
10	721-111	Retaining ring	1x	36	721-137	Chicken feet L+R (pair)	1x
11	721-112	Tension pin	1x	37	721-160-10	Fork body assembly complete Pos. 30 / 31 / 32 / 33 / 34 / 35 / 36	1x
12	721-113	Tension sleeve upper	1x	38	721-139	Ferrule DT Ø22 x 180mm	
13	721-114	Tension nut	1x	38	722-224	Ferrule flexible shaft Ø22 x 160mm	
14	721-145	Distance washer	1x		721-140	Tool kit bearing OMEGA94/ICON 721-144 / 721-150 / 721-151 / 721-152 / 721-153 721-154 / 721-155 / 721-157	
15	721-115	Ball bearing front	1x		721-144	Centre post guide+Cutter OMEGA94/ICON	
16	721-116	Spring washer	1x		721-151	Tool 1 OMEGA94/ICON	
17	721-117	Gliding bush	1x		721-152	Tool 2 OMEGA94/ICON	
18	721-119	Retaining ring JV 27 x 1.2 Typ J	1x		721-153	Tool 3 OMEGA94/ICON	
19	721-118	Seal	1x		721-154	Tool 4 OMEGA94/ICON	
20	721-175	Back joint cover ICON FX	1x		721-155	Seeger circlip pliers OMEGA94/ICON	
21	721-124	Back joint cap	2x				
22	721-121	Back joint spring	1x		721-162	Set of spare parts large OMEGA94/ICON Pos. 2 / 3 / 6 / 11 / 12 / 26 / 32 / 34 / 35	
23	721-123	Inner back joint	1x		721-163	Set of spare parts small OMEGA94/ICON Pos. 2 / 11 / 12 / 32 / 34 / 35	
24	721-146	Outer back joint	1x		721-164	Set of spare parts bearing ICON Pos. 14 / 15 / 16 / 18 / 19 / 25	